Sunwire® CALCULATOR

Introducing the Sunwire ribbon calculator

While it is often difficult to predict some things about the solar industry, you can now rely on the Sunwire ribbon calculator to calculate your solar ribbon needs.

Knowing your solar ribbon is critically important to solar module efficiency and life cycle. Solar ribbon width and thickness have to be carefully adapted to accommodate the limitations of module materials. In addition, the yield strength, thickness and width of solar ribbon can directly influence production yields and decrease cell to module (CTM) losses by 20-30%.

But what if you could go one step further?

What if you could optimise the amount of Sunwire ribbon per spool to accommodate the speed of your tabbing machine or shift changes? What if you could optimise the module materials and Sunwire ribbon for improved module efficiency and reduce overall material costs?

Now you can.

Calculate with Sunwire Calculator:

- ribbon weight
- ribbon length per spool
- ribbon length per solar panel



yields and decrease cell to module (CTM) losses by 20-30%.

www.luvata.com/sunwire-calculator

Using the Sunwire Calculator

By inputting a few simple details, the Sunwire calculator helps you determine the ribbon weight, the ribbon length per spool and even the ribbon weight per solar panel.

Copper width (A)
Copper thickness (B)
Coating thickness (C)

Calculate


Calculate

Calculate

Calculate Sunwire ribbon length per solar panel Number of cells (A) Number of busbars per cells (B) Calculate Calculate

The results are available immediately or emailed directly to your email address.

Yes - it's really that easy.





www.luvata.com/sunwire-calculator

Luvata Sunwire® Manufacturing Facilities:

Luvata Appleton
Kimberly, WILISA

Copyright © 2018 Luvata

Kimberly, WI USA Phone: +920 749 3820 or Toll Free: +800 749 5510 Luvata Pori Oy

Pori, Finland

Phone: +358 2 626 6111

Luvata Malaysia Sdn Bhd

Pasir Gudang, Johor Malaysia Phone: +607 252 6688 MM Metal Products (Suzhou) Co., Ltd

Suzhou, China

Phone: +86 512 6285 1018

Go to www.luvata.com for a complete listing of all our locations.

www.luvata.com/sunwire